













Instruction Manual

Thank you for choosing the StorEase Power Tool Caddy.

Designed for durability and versatility, this innovative storage solution helps you maximise space in your garage, workshop, or shed. With simple installation, it ensures your tools are organised and easily accessible whenever you need them. Let's get started!

PART LIST

Part Code	Part Shape	Descriptions	Qty	Part Code	Part Shape	Descriptions	Qty
A		Back Panel	1	F		Drill Holder	1
B		Left Side Panel	1	G		M5 Nut	12
C		Right Side Panel	1	H		M5*8mm Bolt	8
D		Shelf	2	I		M4.8*50.8mm Mounting Screw	4
E		Bottom Holder	1	J		Plastic Anchor	4
		Spare Bolt	2			Spare Nut	2

ASSEMBLY GUIDE

Follow these instructions to correctly assemble your unit. Ensure all parts are accounted for before starting. Use the provided hardware for a secure and sturdy assembly.



TOOLS REQUIRED



Note: Tools and 6mm Drill Bit Required (Not Included)


● Step 1: Side Panel Connection

Connect the left and right side panels to the back panel. Secure the panels using Part G (M5 Nut), as shown in the diagram. Continue through the subsequent steps, ensuring all connections are properly aligned and tightened for stability.




- **Step 2: Shelf Installation (Part Code D x 2)**

Cross-lock the shelf to the bottom of the back panel, then lay the shelf flat as shown in the image below. Secure the shelf using Part G & H. Repeat this step to assemble the top shelf, following the image for reference.



- **Step 3: Bottom Holder Attachment**

Attach the bottom holder using Part G & H. Position the drill holder onto the side panel as shown in the image below.



INSTALLATION GUIDE

- **Step 1:** Position the caddy on the wall at the desired height and mark the hole positions (see Image 1 below).
- **Step 2:** For concrete or brick walls, pre-drill holes using an 8mm diameter drill bit. Insert the provided plastic anchors and ensure they are flush with the wall.
- **Step 3:** Secure the caddy to the wall using a screwdriver or power drill and the provided screws (see Image 2 below for reference).

