













# Instruction Manual

Thank you for choosing the StorEase Aerosol Can/Spray Bottle Caddy.

Engineered for durability and versatility, this innovative storage solution is designed to help you maximize space in your garage, workshop, or shed. With a straightforward installation process, it keeps your cans and bottles organized, safe, and easily accessible whenever you need them.

Let's get started!

Part Code	Part Shape	Descriptions	Qty	Part Code	Part Shape	Descriptions	Qty
A		Left Stud	1	G		Paper Towel Connecting Supports	1
B		Right Stud	1	H		Plastic Cap paper Towel Tube	20
C		Bottle Holder	2	I		M6 Nuts & Bolts	4
D		Shelf	2	J		Mini Hooks	4
E		Support Plate	1	K		M4.8*50.8mm Mounting Screw	4
F		Paper Towel Holder Tube		L		Plastic Anchor	

## TOOLS REQUIRED



**Note:** Ensure the mounting location can support the additional load. Verify that the mounting bar is correctly oriented, both in its facing direction and vertical alignment, before installation

Note: Tools and Drill Bit Required (Not Included)

### Left stud




↑ this side up

### Right stud




↑ this side up

\*For the convenience of assembly, please remove the end cap at both ends of the stud before assembly.




STEFANI AUSTRALIASIA PTY LTD  
80 PILBARA STREET,  
WELSHPOOL WA 6106  
ABN 18 054 981 421


# Assembly Instructions




**Step 1:** Connect the left and right-side panels to the top back panel. Secure the connection using the provided screws as shown in the diagram.




**Step 2:** Attach the first angled shelf to the side panels using the screws provided. Ensure it is properly aligned, as shown in the image.




**Step 3:** Repeat Step 2 to attach the second angled shelf below the first, ensuring consistent alignment.




**Step 4:** Secure the bottom shelf between the side panels using the provided screws. Confirm that all shelves are tightly fastened.




**Step 5:** Attach the support hooks to the bottom shelf. Tighten them firmly using the screws provided, as depicted in the diagram.



**Step 6:** Affix the rod holder below the bottom shelf. Ensure it is securely in place using the provided screws.




**Step 7:** Attach the towel or accessory rod to the base of the structure. Tighten the screws to secure it in position.




**Step 8:** Place the completed caddy on the wall at the desired height. Mark the positions for drilling holes in the wall (refer to the image for guidance).



**Step 9:** For concrete or brick walls: Pre-drill holes using an 8mm drill bit. Insert the plastic anchors so they sit flush with the wall. Mount the screws and leave a 5mm gap for hanging the rack. For wooden stud walls: Skip the predrilling step and directly secure the rack with wood screws.



**Max Weight 45kg**



\*The mini hook can be hung on the side.\*